




主體型號：  
MW-125WS  
MW-125WSS  
MW-125H  
MW-125WR  
MW-125WRR




把手尺寸




主體型號：  
MW-250WS  
MW-250WSS  
MW-250H  
MW-250WR  
MW-250WRR




把手尺寸




主體型號：  
HW-400WS  
HW-400H  
HW-400WR




把手尺寸



主體型號：  
HW-630WS、HW-630H  
HW-800HS、HW-800H  
HW-800WR




把手尺寸




圖樣單位(A)：  
800A, 10mm  
630A, 8mm


主體型號：  
HW-1200H  
HW-1200WR



把手尺寸



主體型號：  
HW-1600H



把手尺寸

