Three-phase monitoring relay CM-PFS

The CM-PFS is a three-phase monitoring relay that is used to monitor three phase mains for incorrect phase sequence and phase failure.

All devices are available with two different terminal versions. You can choose between the proven screw connection technology (double-chamber cage connection terminals) and the completely tool-free Easy Connect Technology (Push-in terminals).



Characteristics

- Monitoring of three-phase mains for phase sequence and failure
- Suitable for railway applications
- Powered by the measuring circuit
- Closed-circuit principle
- Screw connection technology or Easy Connect Technology available
- Housing material for highest fire protection classification UL 94 V-0
- Tool-free mounting on DIN rail as well as demounting
- 2 c/o (SPDT) contacts
- 22.5 mm (0.89 in) width
- 2 LEDs for the indication of operational states
- Various certifications and approvals (see overview, document no. 2CDC112246D0201)

Order data

Three-phase monitoring relay

Туре	Rated control supply voltage = measuring voltage	Connection technology	Order code
CM-PFS.P	3 x 200-500 V AC	Push-in terminals	1SVR740824R9300
CM-PFS.S	3 x 200-500 V AC	Screw type terminals	1SVR730824R9300

Accessories


Туре	Description	Order code
ADP.01	Adapter for screw mounting	1SVR430029R0100
MAR.01	Marker label	1SVR366017R0100
COV.11	Sealable transparent cover	1SVR730005R0100



Connection technology

Maintenance free Easy Connect Technology with push-in terminals

Type designation CM-xxS.yyP




Push-in terminals

- Tool-free connection of rigid and flexible wires with wire end ferrule
- Easy connection of flexible wires without wire end ferrule by opening the terminals
- No retightening necessary
- One operation lever for opening both connection terminals
- For triggering the lever and disconnecting of wires you can use the same tool (Screwdriver according to DIN ISO 2380-1 Form A 0.8 x 4 mm (0.0315 x 0.157 in), DIN ISO 8764-1 PZ1 Ø 4.5 mm (0.177 in))
- Constant spring force on terminal point independent of the applied wire type, wire size or ambient conditions (e. g. vibrations or temperature changes)
- Opening for testing the electrical contacting
- Gas-tight

Approved screw connection technology with double-chamber cage connection terminals

Type designation CM-xxS.yyS




Double-chamber cage connection terminals

- Terminal spaces for different wire sizes: fine-strand with/without wire end ferrule
- One screw for opening and closing of both cages
- Pozidrive screws for pan- or crosshead screwdrivers according to DIN ISO 2380-1 Form A 0.8 x 4 mm (0.0315 x 0.157 in), DIN ISO 8764-1 PZ1 Ø 4.5 mm (0.177 in)

Both the Easy Connect Technology with push-in terminals and screw connection technology with double-chamber cage connection terminals have the same connection geometry as well as terminal position.

Functions

Operating controls



1 Indication of operational states

R: yellow LED – status indication of the output relays

F: red LED - fault message

Application

The CM-PFS is used to monitor three-phase mains for incorrect phase sequence and phase failure.

Operating mode

The three-phase main to be monitored is connected to terminals L1, L2, L3 in accordance to the wiring diagram.

The device operates according to the closed-circuit principle — incorrect phase sequence or phase failure: relays deenergize.

The signalling of status indication is made by means of the front-face LEDs.


Function diagram

Phase sequence and phase failure monitoring


If all phases are present with the correct phase sequence, the output relays energize after the start-up delay t_s is complete. If a phase failure or a phase sequence error occurs, the output relays de-energize instantaneously.

The LED R is on when output relays are energized.

In case of motors which continue running with only two phases, the CM-PFS detects phase failure if the reverse fed voltage is less than 60% of the originally applied voltage.



Electrical connection



Connection diagram

Technical data

Data at T_a = 25 °C and rated values, unless otherwise indicated

Input circuits

nput circuits	
Supply circuit = measuring circuit	L1, L2, L3
Rated control supply voltage U _s = measuring voltage	3 x 200-500 V AC
Rated control supply voltage U _s tolerance	-15+10 %
Rated frequency	50/60 Hz
Frequency range	45-65 Hz
Typical current / power consumption 400 V AC	16 mA / 11 VA
	14.10.10
Measuring circuit	L1, L2, L3
Monitoring functions	phase failure
	phase sequence
Measuring range	3 x 200-500 V AC
Threshold value for phase failure U_{min}	0.6 x U _n
Hysteresis related to the threshold value	-
Response time	500 ms
Timing circuit	
Start-up delay t _S	fixed 500 ms

User interface

Indication of operational states		
Relay status R1, R2	R: yellow LED	Output relay energized
Fault message	F: red LED	Phase failure
		Phase sequence error

Output circuits

Kind of output	11(15)-12(16)/14(18)	relay, 1st c/o (SPDT) contact
	21(25)-22(26)/24(28)	relay, 2nd c/o (SPDT) contact
		1 x 2 c/o (SPDT) contacts
Operating principle		closed-circuit principle 1)
Contact material		AgNi alloy, Cd free
Rated operational voltage U _e		250 V AC
Minimum switching voltage / Minimum	switching current	24 V / 10 mA
Maximum switching voltage / Maximum	n switching current	see "Load limit curves" on page 7
Rated operational voltage U _e and	AC-12 (resistive) at 230 V	4 A
rated operational current I _e	AC-15 (inductive) at 230 V	3 A
	DC-12 (resistive) at 24 V	4 A
	DC-13 (inductive) at 24 V	2 A
AC rating	utilization category	B 300 pilot duty;
(UL 508)	(Control Circuit Rating Code)	general purpose 250 V, 4 A, cos phi 0.75
	max. rated operational voltage	300 V AC
	max. continuous thermal current at B 300	5 A
max. n	naking/breaking apparent power at B 300	3600/360 VA
Mechanical lifetime		30 x 106 switching cycles
Electrical lifetime	AC-12, 230 V, 4 A	0.1 x 10 ⁶ switching cycles
Maximum fuse rating to achieve	n/c contact	6 A fast-acting
short-circuit protection	n/o contact	10 A fast-acting
Conventional thermal current I _{th}		4 A

 $^{^{\}scriptsize 1)}$ Closed-circuit principle: output relays de-energize if the measured value exeeds/drops below the threshold.

General data

MTBF		on request	
Duty cycle		100 %	
Dimensions		see "Dimensional drawings"	
Weight		Screw connection	Easy Connect Technology
		technology	(push-in)
	net	0.128 kg (0.282 lb)	0.120 kg (0.265 lb)
Mounting		DIN rail (IEC/EN 60715), snap-on mounting without any tool	
Mounting position		any	
		≥ 10 mm (0.39 in) in case of continuous measuring voltage > 440 V	
Degree of protection housing / terminal		IP50 / IP20	

Electrical connection

		Screw connection technology	Easy Connect Technology (push-in)
Connnecting capacity	fine-strand with(out) wire end ferrule	1 x 0.5-2.5 mm ²	2 x 0.5-1.5 mm ²
		(1 x 18-14 AWG)	(2 x 18-16 AWG)
		2 x 0.5-1.5 mm ²	
		(2 x 18-16 AWG)	
	rigid	1 x 0.5-4 mm ²	2 x 0.5-1.5 mm ²
		(1 x 20-12 AWG)	(2 x 20-16 AWG)
		2 x 0.5-2.5 mm ²	
		(2 x 20-14 AWG)	
Stripping length		8 mm (0.32 in)	
Tightening torque		0.6 - 0.8 Nm	-
		(7.08 lb.in)	
Recommended screw driver		DIN ISO 2380-1: Form A / 0.8x4.0 mm DIN ISO 8764-1: PZ 1 / Ø 4.5 mm	-

Environmental data

Ambient temperature ranges	operation	-25+60 °C
	storage	-40+85 °C
	transport	-40+85 °C
Climatic class	IEC/EN 60721-3-3	
Damp heat, cyclic	IEC/EN 60068-2-30	6 x 24 cycle, 55 °C, 95 % RH
Vibration, sinusoidal		Class 2
Shock		Class 2

Isolation data

Rated insulation voltage U _i	input circuit / output circuit	
	output circuit 1 / output circuit 2	
Rated impulse withstand voltage U _{imp}	input circuit / output circuit	
	output circuit 1/output circuit 2	
Basic insulation	input circuit / output circuit	
Protective separation	input circuit / output circuit	n/a
(IEC/EN 61140, EN 50178)		
Pollution degree		3
Overvoltage category	•	III

Standards / Directives

Standards	IEC/EN 60947-5-1, IEC/EN 60255-27, EN 50178	
Low Voltage Directive	2014/35/EU	
EMC directive	2014/30/EU	
RoHS directive	2011/65/EU	

Railway application standards

EN 50155, IEC 60571	temperature class	ТЗ
"Railway applications – Electronic equipment used on rolling stock"	supply voltage category	S1, S2, C1*), C2*)
IEC/EN 61373 "Railway applications – Rolling stock equipment – Sho	ock and vibration tests"	Category 1, Class B
EN 45545-2 Railway applications – Fire protection on railway vehicles – part 2: Requirements for fire behavior of materials		HL3
and components	ISO 4589-2	LOI 32.3 %
·······	NF X-70-100-1	C.I.T. (T12) 0.45
	EN ISO 5659-2	Ds max (T10.03) 104
NF F 16-101: Rolling stock. Fire behaviour. Materials choosing NF F 16-102: Railway rolling stock. Fire behaviour. Materials choosing, application for electric equipment		12 / F2
DIN 5510-2 Preventive fire protection in railway vehicles. Part 2: Fire behaviour and fire side effects of materials and parts		fullfilled


^{*)} only applicable for devices with DC supply

Electromagnetic compatibility


Interference immunity to		IEC/EN 61000-6-2	
electrostatic discharge	IEC/EN 61000-4-2	Level 3, 6 kV / 8 kV	
radiated, radio-frequency, electromagnetic	IEC/EN 61000-4-3	Level 3, 10 V/m (1 GHz) / 3 V/m (2 GHz) / 1 V/m (2.7 GHz)	
field			
electrical fast transient/burst	IEC/EN 61000-4-4	Level 3, 2 KV / 5 kHz	
surge	IEC/EN 61000-4-5	Level 3, 2 kV L-L	
conducted disturbances, induced by radio-	IEC/EN 61000-4-6	Level 3, 10 V	
frequency fields			
voltage dips, short interruptions and	IEC/EN 61000-4-11	Class 3	
voltage variations			
harmonics and interharmonics	IEC/EN 61000-4-13	Class 3	
Interference emission		IEC/EN 61000-6-3	
high-frequency radiated	IEC/CISPR 22, EN 55022		
high-frequency conducted	IEC/CISPR 22, EN 55022	Class B	

Technical diagrams


Load limit curves



AC load (resistive)




DC load (resistive)




Contact lifetime

Dimensions


in mm and inches




Accessories



ADP.01 - Adapter for screw mounting



MAR.01 - Marker label



COV.11 - Sealable transparent cover

Further documentation

Document title	Document type	Document number
Electronic relays and controls	Catalog	2CDC 110 004 C02xx
CM-PAS, CM-PFS, CM-PSS, CM-PVS	Instruction manual	1SVC 630 510 M0000

You can find the documentation on the internet at www.abb.com/lowvoltage

-> Automation, control and protection -> Electronic relays and controls -> Measuring and monitoring relays.

CAD system files

You can find the CAD files for CAD systems at http://abb-control-products.partcommunity.com

-> Low Voltage Products & Systems -> Control Products -> Electronic Relays and Controls.

Contact us

ABB STOTZ-KONTAKT GmbH

P. O. Box 10 16 80 69006 Heidelberg, Germany Phone: +49 (0) 6221 7 01-0 Fax: +49 (0) 6221 7 01-13 25 E-mail: info.desto@de.abb.com

You can find the address of your local sales organisation on the ABB home page http://www.abb.com/contacts -> Low Voltage Products

Note:

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB AG does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB AG.

Copyright© 2017 ABB All rights reserved